

hp LaserJet 4345mfp


Using the control panel

More help




See the user guide

or



Visit www.hp.com/support/lj4345mfp




Use this feature to adjust the control panel contrast.



Use this feature to select the pop-up style "what's this?" help or print step-by-step instructions by using "show me how."

MENU opens the device menus, including "Retrieve Jobs."



SLEEP


STATUS shows the current supply status.

STOP cancels a current job.

RESET returns the device to configured defaults.


START

Describes the original document.




Describes the copied output, including finishing options.

Use these controls to adjust the size and the density of the scanned image.



Use this feature to send your document in e-mail.



Use this feature to fax your documents to a standard fax machine. Fax settings and speed dials can also be selected here.

Copy

Simple Copy

1. Place the original on the glass or face-up in the ADF; Touch START.

Advanced Copy

1. Place the original on the glass or face-up in the ADF.
2. Touch COPY.
3. Touch DESCRIBE ORIGINAL.
4. Select options, such as size, lightness or darkness, and 1-sided or 2-sided.
5. Touch COPY SETTINGS.
6. Select options, such as size, collation, and 1-sided or 2-sided.
7. Touch START.



E-mail

1. Place the original on the glass or face-up in the ADF.
2. Touch E-MAIL.
3. If requested, type your user name and password.
4. Complete the remaining fields.
5. Select the settings you want to use by touching Settings and then touching OK, or use the default settings.
6. Press the START button.



Fax

1. Place the original on the glass or face-up in the ADF.
2. Touch FAX.
3. Touch Settings and describe the original.
4. Use the keyboard to type the phone number.



Advanced Features

1. Touch ?
2. Touch Show Me How.
3. Scroll to and touch a topic.
4. The instructions automatically print.




- * Quick Copies
- * Copy 1-sided to 2-sided (1 to 2)
- * Copy 2-sided to 1-sided (2 to 1)
- * Copy 2-sided to 2-sided (2 to 2)
- * Handouts (Multiple pages per sheet or N-up)
- * Make a booklet
- * Storing a Copy Job
- * Retrieving a Stored Copy Job
- * Create a job with Multiple Size Originals
- * Choose an Output Bin

- * Send an E-mail
- * Save an E-mail Address

- * Send a Fax
- * Send a Fax to a Speed Dial
- * Create a New Fax Speed Dial
- * Delete Fax Speed Dial

www.hp.com/go/useMyMFP






hp LaserJet 4345mfp

使用控制面板

更多說明




使用此功能可調整控制面板對比。



使用此功能可選擇快顯樣式的「這是什麼？」說明，或利用「使用方法」來列印逐步指示。

「功能表」可開啟裝置功能表，包括「擷取工作」。



「睡眠」


「狀態」
可顯示目前的耗材狀態。

「停止」
可取消目前的工作。

「重設」
可使裝置回到設定的預設值。


「開始」

描述原始文件。




描述影印輸出，
包括完成選項。

使用這些控制
可調整掃描影像
的尺寸和濃度。



使用此功能可在電
子郵件中傳送文件。



使用此功能可將文件傳真
到標準傳真機。
您也可以在此處選擇傳真
設定值和快速撥號。

影印

簡易影印

1. 原稿放在玻璃上，或是面朝上放入 ADF；
點選「開始」。

進階影印

1. 原稿放在玻璃上，或是面朝上放入 ADF。
2. 點選「影印」。
3. 點選「描述原稿」。
4. 選擇例如尺寸、明暗和單雙面等選項。
5. 點選「影印設定值」。
6. 選擇例如尺寸、分頁和單雙面等選項。
7. 點選「開始」。



電子郵件

1. 將原稿放在玻璃上，或是面朝上放入 ADF。
2. 點選「電子郵件」。
3. 如果系統要求，請鍵入您的使用者名稱和密碼。
4. 完成剩餘的欄位。
5. 依序點選「設定值」和「確定」
可選擇您想使用的設定值，或使用預設設定值。
6. 按下「開始」按鈕。



傳真

1. 將原稿放在玻璃上，或是面朝上放入 ADF。
2. 點選「傳真」。
3. 點選「設定值」並描述原稿。
4. 使用鍵盤鍵入電話號碼。



進階功能

1. 點選 ?
2. 點選「使用方法」。
3. 捲動並點選主題。
4. 這樣會自動列印指示。



- * 送出電子郵件
- * 儲存電子郵件位址

- * 快速影印
- * 將單面影印成雙面 (1 到 2)
- * 將雙面影印成單面 (2 到 1)
- * 將雙面影印成雙面 (2 到 2)
- * 講義 (每張列印多頁或 N-up 功能)
- * 製作手冊
- * 儲存影印工作
- * 擷取儲存的影印工作
- * 建立具有多重尺寸原稿的工作
- * 選擇出紙槽

- * 送出傳真
- * 將傳真送至快速撥號
- * 建立新傳真快速撥號
- * 刪除傳真快速撥號